



COMPOSITE PANEL SYSTEM (DRY JOINT)






HORIZONTAL JOINT DETAIL






VERTICAL JOINT DETAIL






COPING DETAIL (1)






COPING DETAIL (2)






COPING DETAIL (3)






OUTSIDE CORNER DETAIL






SOFFIT DETAIL






WINDOW JAMB DETAIL






WINDOW HEAD DETAIL






WINDOW SILL DETAIL






GLAZED PANEL DETAIL (1)






GLAZED PANEL DETAIL (2)






BASE DETAIL






INSIDE CORNER DETAIL (1)






INSIDE CORNER DETAIL (2)





COMPOSITE PANEL SYSTEM (DRY JOINT) INSTALLATION GUIDE



- 3 SLIDE DOUBLE DRY-CLIPS AT 16" O.C. ON TO STARTER PANEL SHOP ATTACHED PERIMETER CHANNEL FOR EDGES WITH ADJACENT PANELS FASTEN ONE CLIP TO CHANNEL PER PANEL
- (4) PLACE STARTER PANEL ON BASE EXTRUSION AND FASTEN DRY-CLIPS TO SUBSTRATE
- (5) REPEAT STEPS 2, 3 AND 4 FOR ADJACENT PANELS
- (6) INSERT JOINT COLOR STRIPS BETWEEN PERIMETER CHANNELS AND DRY-CLIPS